

USB-A is the type of connector which plugs into your laptop. USB-B is the end that plugs into your printer.

High quality braided shield and ferrite core connector at both ends to shield against EMF and RF interference.