

vav.link/vfm-f26m/

VISION

1

OPTIONAL

OR

1 **2**


(A) M8x45mm x12

(B) D8 x12


(C4) 5mm x1

(C) 5mm x1


2




3




4




5




6




7






8




9




Step1**Step2****Step3**


11




12




13





14







OPTIONAL





16





17






 x4
M4x10mm


 x4
M4*30mm+6mm



6mm












4mm






OPTIONAL



20



21

After installation, you must press and hold the "Up" button to reset the system. The device is ready for normal use once the reset is complete.

